




ASSEMBLY MANUAL



INTRODUCTION

Esteemed friend, thank you for your purchase of the CONTRAST QUATTRO 4WD. This product that you are going to assemble is the result of many years of testing, study and development by a large team of highly qualified people. The aim of CONTRAST project is to offer you a high competition car of scale 1:5 with more features and possibilities than the rest of the existing models and brands. But we also wanted to create a simple car, easy to assemble and dismantle, resistant to bumps and to wear and tear, with a high quality manufacturing and besides... it had to be light.

I believe we have achieved that complex aim with the car you have in your hands, and because of this we hope that you enjoy assembling your CONTRAST QUATTRO and get excite about pushing it to the limit on the track.

CONTRAST is an open-minded brand and we wish to know our customer's opinions, as well as the proposals, criticisms, complaints and everything you want to communicate to us, without forgetting the ideas you may have to make the car evolve. You can get into touch with us either by the postal address below or through the next links in internet:

Web official: www.contrast-racing.com

Facebook: Contrast Racing - the offiial site

Twitter: Contrast_Racing

Now you are part of the CONTRAST TEAM
Yours sincerely

Daniel Fuertes Contrast Manager

CONTRAST RACING S.L.

Ses Falques 4, local 13 17300 Blanes (Girona) Spain info@contrast-racing.com

You will find more information and news about Contrast products on our webs site:

www.contrast-racing.com/www.contrast-racing.com/shop

WARNINGS:

- Before starting the assembly read carefully the first pages of this handbook.
- Follow this handbook's instructions through the assembly to get a proper assembly and a perfect adjustment of all the pieces.
- Keep this handbook after the assembly as it may be a help at any moment.
- Contrast Quattro has been designed to be used on smooth asphalt surfaces. Any use out of these conditions may cause breaking or premature wear and tear of its mechanical pieces.
- Use original spares and replace worn pieces by the same reference number from the Contrast listing. The use of other brands may cause bad behaviour of the vehicle or even a breakdown.
- Contrast Racing S.L. does not take any responsibility for the use that may be given to this product.
- No section of this handbook can be reproduced without a previous consent.
- Due to the continuous evolution of our products, it is possible that any image or explanation of this handbook does not coincide exactly with the real pieces they refer to.

REQUIRED EQUIPMENT

For the right working of the Contrast Neo you will need the following additional equipment, not included in the kit:



Two or three channel transmitter with batteries, receiver and frequency.



Two or three standard or big size 1:5 servos



Battery pack for the radio system and servos' working



Unleaded petrol mixed with

NECESSARY TOOLS



Allen tools 1.5, 2, 2.5, 3, 4 y 5



plane tools 5.5, 7, 8, 10, 13, 17



Screwdriver, philips type



Screwdriver plane



cut pliers



Tip pliers



Clips pliers



Cutter



Scissors



Calibre



Plastic hammer



grease and oils



Soft screwlock




Medium screwlock





Alcohol or cleaners

CONTRAST QUATTRO ASSEMBLY MANUAL











Before assembling the shock absorbers verify that the movement of the wishbones is soft in its entire course with no frictions or hard points.







STEP 6 - SERVO SAVER


The servosaver is a really very important piece in the car. This servosaver is adjustable in hardness with the wingnut that presses the conic shims which work as hard spring. Adjust the nut M8 till start to pres the washers. The good preassure is when the Nut and the upper side of brass shaft are in same higher.


























Fill the differential with a little quantity of white hard grease Contrast. In good conditions of adherence in track is possible to fill the diff till 50% of his volumen or more.



Fill the differential with high quantity of white hard grease Contrast. In good conditions of adherence in track is possible to fill the diff till 50% of his volumen or more.




STEP 17 - ADJUSTABLE CLUTCH




Use 4 x screws M5x8 inside the shoes and/or 4 shoes only if you want a soft performance as in rainy conditions or off road use. If you want a hard and fast racing acceleration use only two red shoes with 3.0 spring and no screws inside.

SPRING LEVELS


150202/55 Very soft spring 2,8 mm (optional) 150202/6 Medium spring 2.9 mm (optional) 150202/66 Hard spring 3.0 mm (Include in the kit)




Adjust tension of spring by this special nut using a screwdriver through the clutch bell inside this cut. The correct adjust for on road use is between 9000 rpm to 11.000 rpm




When assembling the O-rings in the piston and assembling the piston into cylinder, smear everything with soft grease; this will improve the bomb softness and will make the life of the joints longer.



When assembling the O-rings in the pistons and assembling the pistons into calliper, smear everything with soft grease; this will improve the softness and will make the life of the joints longer.





STEP 20 - SHOCK ABSORVERS

Optional associated parts:

150120/161 Closed piston shock, 2u.

150120/181 Piston shock set 2holesx1,6, 2u.


150110/x Spring sets

150111/xx Silicon oil

150097 Fast support shocks set 4u.

150101 Carbon front long damperplate

150103 Carbon rear damperplate



STEP 21 - MODIFICATIONS TO PLACE THE ENGINE ZENOAH



Cut this part of the engine cover to allow the installation of the pipe "on the right side"



Cut this paddle to allow the best adjustment with the engine and transmision support, part number 170019

PART NUMBERS 170238 Kit front drive shaft 170092 170238/4 170092 170238/2 170238/3 170238/6 170238/6 170154 Kit servo saver 170057 (left) 170058 (right) 151083 (6mm) 150151 151154/1 150066 151154/2 170154/6 150065 150152 170100 150056/5 170051 170008/1 (left) 170059 (left) 170008/2 (right) 170059/2 (right) 150214 150072 170221 150067 300010 170219 150068/2 170093 170228 300012 170007/2 170001 170006/4 151007/1 170006/5 150021 170301 Radio box 170301/1 151006/1 150023

